

WISDOM


HW1-S246-V01-A



PART LIST



HARDWARE



A

WARNING:

- -Contains small parts, sharp points and edges.
- -Adult assembly required.
- -Two adults recommended.
- -Do not stand, sit, kneel or pull on unit for support.
- -Never leave children unattended.
- -Do not place unit near high heat or moisture.
- -Adult supervision recommended.
- -Clean with a moist cloth.

TIP!
DO NOT FULLY
TIGHTEN SCREWS
UNTIL ALL SCREWS
HAVE BEEN LOOSELY


POSITIONED.


BEFORE ASSEMBLING, MAKE SURE THERE ARE NO MISSING PARTS.

NOTE:

AN ELECTRIC SCREWDRIVER IS RECOMMENDED FOR ASSEMBLY(NOT INCLUDED)







Adjust to proper height for fixation.

Blue liners are supplied as optional extras - they are not necessarily required for soil base. However they will help extend the life of your planter box and will reduce water flow if planter is used on solid

floors (for example concrete)



CAUTION:

- -Do not allow children to climb on shelves.
- -Do not use as a ladder or cart.

CARE AND CLEANING

- -Clean wood with a damp cloth or sponge using warm water and mild soap. Wipe dry.
- -Do not place near heat, moisture or vaporizer which may cause wood to warp and peel.
- -Check for loose or worn parts periodically and tighten or replace as necessary.

1 YEAR LIMITED WARRANTY

We will supply, without charge, any part discovered to be missing at the time of purchase or found to be defective during the 1-year

warranty period. The warranty begins on the date of purchase. We will replace without charge any part found to be missing at the time of purchase, damaged on delivery or

cosmetic issues or failures due to misuse or vandalism. Natural changes in wood over time are considered cosmetic issues and

located on a label enclosed, and on the shipping carton. Place label and this sheet in an accessible place.